




Nº	FUNCTION	Nº	FUNCTION
1	INJECTION RELAY	15	TEMPERATURE SENSOR FANS
2	FAN RELAY	16	HORN
3	LIGHTS RELAY	19	FUEL LEVEL SENSOR
4	INDICATORS RELAY	20	INJECTION HARNESS COUPLING
5	IGNITION KEY	21	VOLTAGE REGULATOR
6	POWER CUT STARTER BUTTON	22	REAR LIGHT
7	LIGHT SWITCH	23	REAR INDICATORS
8	LIGHTS/DIGITAL DASHBOARD	24	REAR LIGHT STOP
9	DIGITAL DASHBOARD	25 A	FUSE BOXES 10 A
10	RPM/DIGITAL DASHBOARD	25 B	FUSE BOXES 15 A
11	FRONT STOP	25 C	FUSE BOXES 20 A
12	FRONT INDICATORS	26	BATTERY POSITIVE SIDE
13 A	LEFT RADIATOR FAN	27	BATTERY NEGATIVE SIDE
13 B	RIGHT RADIATOR FAN	28	STARTER RELAY
14	FANS DIODE	29	STATOR

COLOR CODE	
YE	YELLOW
RD	RED
BK	BLACK
BU	BLUE
BR	BROWN
GN	GREEN
VI	VIOLET
WH	WHITE
GY	GREY
PK	PINK
OR	ORANGE

-	WH-BR	-
YE-GN	WH-RD	BU-BK
WH-YE	BK	RD



1


2

3

4

5

6.



7

8

9.

10

11

12

13

14



WH-RD	VI
WH-BK	GY

WH-BK	RD-BK
WH-BU	

Nº	FUNCTION	Nº	FUNCTION
1	ECU	8	TEMPERATURE SENSOR
2	ECU	9	IGNITION COIL
3	ELECTRICAL HARNESS	10	OXYGEN SENSOR
4	INJECTOR	11	TPS SENSOR
5	FUEL PUMP	12	STEPPER SENSOR
6	NEUTRAL POSITION SENSOR	13	MAP/MAT SENSOR
7	CRANCKSAFT POSITION SENSOR	14	OBD CONNECTOR

COLOR CODE	
YE	YELLOW
RD	RED
BK	BLACK
BU	BLUE
BR	BROWN
GN	GREEN
VI	VIOLET
WH	WHITE
GY	GREY
PK	PINK
OR	ORANGE